

**ComilDE** ..... 1  
    EtherCAT ..... 1  
    NEMO ..... 1  
    ETC ..... 1

# 1.3.8.9

## ComilDE

### EtherCAT

- Initial AI-State option 가
- ErrorCount Check option 가
- DLL Logger
  - Include List 가
  - Memory Logging Stop 가
- Configuration
  - Device 가 2 Device가
  - Slave DI / DO 256 255 (TEcDiChanMap NuimChans byte)
  - BaseAddress
  - PDO, Entry xml
  - InfoReference (Module 가 xml )
  - PhysicsType read 가 ("YY " hub )
  - DcSync Unused FreeRun (ELMO)
- RDP 가

### NEMO

- NEMO2
- Firmware Updater : NEMO2
- HomeSetSpeed phase

### ETC

- UnLoadDevice IDE
- IDE Log 가
- Shell : IDE Logging , File Write

From:  
<http://comizoa.co.kr/info/> - -

Permanent link:  
[http://comizoa.co.kr/info/doku.php?id=application:comiide:20\\_intro:10\\_history:1.3.8.9&rev=1663561855](http://comizoa.co.kr/info/doku.php?id=application:comiide:20_intro:10_history:1.3.8.9&rev=1663561855)

Last update: **2024/07/08 18:23**