

Form	1
Monitor Name	1
Common	2
Graph	3
DLL Log	3

Form

X

Form

Setup

Basic

Platform

Form

HotKey

Device

EtherCAT

EtherCAT IP

OK

Cancel

Monitor Name

Axis Name

☒ Custom

☐ Base Axis 0

☐ Base Axis 1

☐ ID (Hexa)

☒ ID (Decimal)

IO Channel

☐ Custom

☐ Dec Global

☐ Dec Local

☒ Hex Global

☐ Hex Local

Common

Log File Size (MB)

10

Log Folder Size (MB)

1024

Graph

BufferSize

50000

UpdateInterval

10

DLL Log

BufferSize (Lines)

4000

- Setup **Form**
-
- IDE

Monitor Name

Axis Name :

- Custom : 'Axis ##' , 가

- Base Axis 0 : 'Axis ##' , 'Axis 0' . Driver Rotary
 - 1
 - 'Driver 1' 'Axis 0' .
- Base Axis 1 : 'Axis ##' , 'Axis 1' . Driver Rotary
 - 'Driver 1' 'Axis 1' .
- ID (Hexa) : 16
 - 'Base Axis 1' , 'Driver 10' 'Axis A' .
- ID (Decimal) : 10
 - 'Base Axis 1' , 'Driver 10' 'Axis 10' .
 - 'Base Axis 1' , ID(Hexa), ID(Decimal) , 'Driver 10' 'Axis 10(A)' .

IO Channel : (DI/DO)

- Custom : 'DO ##' / 'DI ##' , 가
- Dec Global : 10 Global .
- Dec Local : 10 Local .
- Hex Global : 16 Global .
- Hex Local : 16 Local .
- **Global Channel** **Slave** 가 .
- **Local Channel** **Slave** 가 0 .
- DI / DO .
- 16 DI , 16 DO , DO
 - Dec Global : DO 26
 - Dec Local : DO 10
 - Hex Global : DO 1A
 - Hex Local : DO A

Common

- Log file Size (MB) : log .
- Log Folder Size (MB) : log
 - log 가 , 가 .

Graph

- BufferSize : .
- UpdateInterval : ms .
- BufferSize : 6000 / UpdateInterval : 10 , 60 .

DLL Log

- BufferSize (Lines) : DLL Logger, Shell Logging , BufferSize line .

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=application:comiide:30_control:10_setup:30_form&rev=1607683867

Last update: **2024/07/08 18:23**