

HotKey	1
Common	1

HotKey

×

Common

- F1 : **F1**
 - Device Emergency : , .
 - Axis Emergency : , .

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=application:comiide:30_control:10_setup:40_hotkey&rev=1607684066

Last update: **2024/07/08 18:23**