

AI State ..... 1  
CRC Error ..... 1

# AI Monitor

× EtherCAT  
AI State

AI-State   CRC Error  
**AI State**

AI Monitor

**AI State**

- AI Monitor <sup>1)</sup>
  - AI State
  - AI State

- AI State 가
- **SafeOP** 가

**CRC Error**

- CRC Error가 "Error Count"

- AI State가 OP 가
- MASTER-DC Error Count , ErrorCount 가

<sup>1)</sup> View Monitor <btn size="xs"> **AIMonitor** </btn>

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

<http://comizoa.co.kr/info/doku.php?id=application:comiide:monitor:almonitor&rev=1542187082>

Last update: **2024/07/08 18:23**