

		1
10		2
16		3

0x00	0x2710	0xFA	0x19	0x19	1%
0x0000	0x100000	0x0000	0x2710	0x2710	
0x0000	0x40000000	0x0001	0x0001	0x0001	
0x0001	0x40000000	0x0001	0x0001	0x0001	
0x0001	0x40000	0x09C4	0x09C4	0x09C4	
0x00	0x03	0x00	0x00	0x00	

KeyPad

0x2710←

<<>>+/-

123OK

456

789Exit

H0.

A B C Dec

D E F Hex

- Cell 16 KeyPad가 .
- Dec 10 KeyPad 가 , 10 KeyPad 10000 10 , 16 .
- 16 KeyPad 2710 10 16 . 16 KeyPad 2710 0x2710 .

10

Category

All

10

16

Item	Name	Minimum	Maximum	Defalut	Servo	Value	Unit
☒	0	0	1	1	1	1	---
☐	1	0	6	0	0	0	---
☐	2	0	6	1	1	1	---
☐	3	0	31	13	14	14	---
☐	4	0	10000	250	25	25	1%
☐	8	0	1048576	0	10000	10000	---
☐	9	0	1073741824	1	1	1	---
☐	10	1	1073741824	1	1	1	---
☐	11	1	262144	2500	2500	2500	1 Pulse/r
☐	12	0	3	0	0	0	---

• 10

Minimum / Maximum / Default / Servo / Value

10

16

Category

All

10

16

Item	Name	Minimum	Maximum	Defalut	Servo	Value	Unit
☒	0	0x00	0x01	0x01	0x01	0x01	---
☐	1	0x00	0x06	0x00	0x00	0x00	---
☐	2	0x00	0x06	0x01	0x01	0x01	---
☐	3	0x00	0x1F	0x0D	0x0E	0x0E	---
☐	4	0x00	0x2710	0xFA	0x19	0x19	1%
☐	8	0x0000	0x100000	0x0000	0x2710	0x2710	---
☐	9	0x0000	0x40000000	0x0001	0x0001	0x0001	---
☐	10	0x0001	0x40000000	0x0001	0x0001	0x0001	---
☐	11	0x0001	0x40000	0x09C4	0x09C4	0x09C4	1 Pulse/r
☐	12	0x00	0x03	0x00	0x00	0x00	---

• 16

Minimum / Maximum / Default / Servo / Value

16

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:servotunes:40_hexa&rev=1542872278

Last update: **2024/07/08 18:23**