

Intro	1
Logging	1
Interval	2
LogType	3

LogMode

× API

LogMode

.

Intro

- LogMoed API Stop API , 1)
- 'Log' LogMode .
- / .

Shell

> log

LOG> list

Clear

Open

API

F3

Exit

ToMem

ToQueue

Stop

Save

Load

Interval

MicroSec (Micro)

MiliSec (Mili)

QueueSize


MemSize (BufSize / BufferSize)

FolderSize (DirSize)

LOG> |

Logging

- API
- ';;' API
- out type parameter "null", logging
- parameter "Invalid parameter", logging
"Logging Start"



```

Shell
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0)
    Invalid parameter
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0, null)
    Logging Start

LOG> stop
    Logging Stopped

LOG> open
LOG> save
    Command Saved

LOG> load
LOG> ecmSxSt_GetPosition(0,0,1,null);ecmSxSt_GetCurTorque(0,0, null)|
  
```

```

LOG> stop
LOG> open
LOG> save
LOG> load
  
```

- stop : logging "Logging Stopped"
- open : logFile
- save :
- load :

Interval

- Logging

```
Shell
> log

LOG> interval
    Interval = 10 ms

LOG> interval(1)
    Log Interval (ms) : 10 → 1

LOG> microsec
    Resolution Changed : MiliSecond → MicroSecond

LOG> interval
    Interval = 1000 us

LOG> interval(500)
    Log Interval (us) : 1000 → 500

LOG> milisec
    Resolution Changed : MicroSecond → MiliSecond

LOG> interval
    Interval = 1 ms

LOG>
```

```
LOG> interval
LOG> interval(1)
LOG> microsec
LOG> interval
LOG> interval(500)
LOG> milisec
```

- interval : log . 10ms .
- interval(1) : log 1ms .
- microsec : log us .
- interval : microsec milisec .
- interval(500) : microsec microsec 가 .

x microsec pc 가 .

LogType

- Memory Queue .



```

Shell
> log

LOG> toqueue
    LogMode : Memory → Queue

LOG> queuesize
    QueueSize = 10000

LOG> queuesize(20000)
    LogMemSize : 10000 → 20000

LOG> tomem
    LogMode : Queue → Memory

LOG> memsize
    LogBufferSize = 50000
  
```

Memory

- MemSize Memory

- , Stop

Queue

- QueueSize , stop

```

LOG> toqueue
LOG> quesize
LOG> quesize(20000)
LOG> tomem
LOG> memsize
LOG> memsize(20000)
  
```

- toqueue : Queue
- quesize : queueSize line
- quesize(20000) : quesize 20000
- tomem : Memory . Shell
- memsize : MemorySize line
- memsize(20000) : MemorySize 20000

Return out

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:shell:shell_logmode&rev=1543282186

Last update: **2024/07/08 18:23**