


.....	1
.....	1

RunTime Mode

× RunTime Mode

API



```
Shell
> runtime
    Mode Changed : NORMAL → RUNTIME


RUNTIME> list
    Clear
    Open
    API
    F3

    Exit

    RunCount

RUNTIME> |
```


- RunTime Mode api , .



```
Shell
RUNTIME> runcount(1)
    RunCount : 100 → 1

RUNTIME> ecmSxSt_GetMotState(0,0,ref error)
    Run Count : 1.
    ElapsedTime : 52 (us)

RUNTIME>
```



```
Shell
RUNTIME> runcount
      RunCount = 1

RUNTIME> runcount(10)
      RunCount : 1 → 10

RUNTIME> ecmSxSt_GetMotState(0,0,ref error)
      Run Count : 10,
      ElapsedTime : 91 (us)
```

```
RUNTIME> runcount
RUNTIME> runcount(10)
```

- RunCount : .
- RunCount(10) : 10 .

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:shell:shell_runtime&rev=1543285393

Last update: **2024/07/08 18:23**