


..... 1
..... 1



```

RUNTIME> runcount
RUNTIME> runcount(10)
  
```

- RunCount : .
- RunCount(10) : 10 .
- exit : RunTime Mode Normal Mode .

× PC , Core, Task, Thread 가 .

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:shell:shell_runtime_mode&rev=1544502913

Last update: **2024/07/08 18:23**