


.....	1
Read / Write	1

EEPROM Update

x EtherCAT Slave EEPROM / CoeSDO / Register read, write .



- ComiIDE Main - Tool II Slaves SlaveRW

Read / Write

Slave RW

03 : [0219] ETS-DI32N-M

EtherCAT

Net 0

00 : [02FF] MASTER-DC

01 : [03FA] ETS-HUB08

02 : [02FA] ETS-HUB08

03 : [0219] ETS-DI32N-M

04 : [0209] ETS-DO32N-M

05 : [02FB] ETS-HUB08

06 : [03FB] ETS-HUB08

07 : [0201] ETS-D08MN

08 : [0202] ETS-D08MN

09 : [03FC] ETS-HUB08

Index Order

ID Order

Info

EEPROM

CoE SDO

Register

Update

Register

Size

Value

Read

Write

1

2

3

4

- List Slave
- EEPROM / Coe SDO / Register
- Read Value Read
- Write Value Write

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

<http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:slaverw:slaverw&rev=1575276364>

Last update: **2024/07/08 18:23**