

Tool	1
Configurator :	1
ServoTunes :	2
Gantry	2
Shell	3

Tool

Configurator :

Configurator Configuration

Config

- Configurator
- Configuration

Description

- Project
 - Slave List
- Setup : Configuration Option
- TopologyView
 - Topology, AIStatus, AIStatus Error ,
 - Port , InPort - OutPort , DC Delay
- Net Info
 - Cycle Time, Process Time, Logic Memory
 - DI, DO, AI, AO Channel Map
- Slave Info
 - Address, SyncMode, DeviceType
- Process Data
- Slot Info
- Addressing
 - IO Module Channel Mapping
 - Auto Addressing
- Distibuted Clock Delay
- Reverse Connected Slave
- Module Change

Trouble Shooting

- [Scan Error](#)
- [Master Device](#)
-
- [Master-DC](#)
- [OP](#)

ServoTunes :

Info

- [ServoTunes?](#)
-

Guide

-
- :
- &
- ()
- [10](#) or [16](#)
- [MotionIO](#) &

Gantry

Info

- [Gantry?](#)
-
-

Guide

-
-
- [Gantry](#)

Trouble Shooting

Shell

Info

- [Shell?](#)

Guide

-
- [Normal Mode : API](#)
- [Log Mode : API](#)
- [RunTime Mode : API](#)
- [Timer Resolution](#)

Trouble Shooting

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

<http://comizoa.co.kr/info/doku.php?id=application:comiide:tool:start&rev=1576383273>

Last update: **2024/07/08 18:23**