



# SW ECAT Master ID, PW

× SW ECAT Master

ID, PW

.

이름	종류	데이터
ab (기보값)	REG_SZ	(값 설정 안 됨)
ab ID	REG_SZ	administrator
ab Password	REG_SZ	administrator

- Windows
- \HKEY\_LOCAL\_MACHINE\SOFTWARE\COMIZOA\SoftEcatMaster\Administrator
- ID, PW or

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

[http://comizoa.co.kr/info/doku.php?id=faq:downloadandsetup:ethercat\\_sw:03\\_id\\_pw](http://comizoa.co.kr/info/doku.php?id=faq:downloadandsetup:ethercat_sw:03_id_pw)

Last update: **2024/07/08 18:23**