

- 1
- PCI 1
- Instance 1
- Pulsemotion, DAQ 1
- Case 1. OS** 1
- 1
- 2
- Case 2.** 2
- 2
- 2
- 2
- Case 3. OS,** 2
- 2
- 3
- See Also 3

Pulsemotion, DAQ

×	Pulsemotion	DAQ	가
×	Instance	Slot	Mainboard

PCI

- PCI
-

Instance

- Instance **Windows** OS
- Instance

Pulsemotion, DAQ

- BoardID ID²⁾가 ID가 OS **Instance**
- 가
- 가 Motion Builder v3 CME2

Case 1. OS

- OS Instance 가 가

- 가 CME2

win7 Mainboard A				win10 Mainboard A				win10 Mainboard A			
no	model	instance	slot	no	model	instance	slot	no	model	instance	slot
0	COMI-LX504	0	7000	0	COMI-LX504	0	7003	0	COMI-LX504	1	7000
1	COMI-LX504	1	7001	1	COMI-LX504	1	7000	1	COMI-LX504	2	7001
2	COMI-LX508	2	7002	2	COMI-LX508	2	7001	2	COMI-LX508	3	7002
3	COMI-LX508	3	7003	3	COMI-LX508	3	7002	3	COMI-LX508	0	7003

Case 2.

- 가 OS가 Instance

- Motion Builder v3
- 가 CME2

win7 Mainboard A				win7 Mainboard B				win7 Mainboard B			
no	model	instance	slot	no	model	instance	slot	no	model	instance	slot
0	COMI-LX504	0	7000	0	COMI-LX504	1	6001	0	COMI-LX504	2	6001
1	COMI-LX504	1	7001	1	COMI-LX504	2	6002	1	COMI-LX504	1	6002
2	COMI-LX508	2	7002	2	COMI-LX508	3	6000	2	COMI-LX508	3	6000
3	COMI-LX508	3	7003	3	COMI-LX508	4	6003	3	COMI-LX508	0	6003
보드 하나씩 연결해서 확인시											
				no	model	instance	slot				
				0	COMI-LX504	2	6001				
				1	COMI-LX504	1	6002				
				2	COMI-LX508	3	6000				
				3	COMI-LX508	0	6003				

Case 3. OS,

- 가 , OS 가

-

See Also

- [CME2](#) [Pulsemotion](#)

1)

[Pulsemotion](#) , [DAQ](#)

2)

[Pulsemotion](#) [LX502 - LX504 - LX508 - LX534](#) [가](#)

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=faq:downloadandsetup:pulsemotion:02_pulsemotion_slot_infomation&rev=1670986162

Last update: **2024/07/08 18:22**