

**Case 1** ..... 1  
    AddInfo ..... 1  
    Cause ..... 1  
    Solution ..... 1  
**Case 2** ..... 1  
    AddInfo ..... 1  
    Cause ..... 1  
    Solution ..... 2

ethercat, , homing, -21070, ,

# Error : -21070

× -21070 (Homming Start Timeout)

## Case 1

**AddInfo**

- (-) 가
- (-) ( NOT )
- -21070 (Homming Start Timeout) 가

**Cause**

- POT 가 (+)

**Solution**

- POT OFF

## Case 2

**AddInfo**

- 가
- , -21070 (Homming Start Timeout) 가
- 

**Cause**

- SDO 0x6080 (Max motor speed) 0 <sup>1)</sup>

**Solution**

