

Configurator	,	
	.	1
		1

Configurator

x Configurator .

Configurator

- Slave
- Slave Topology Map
- Slave Address, SyncMode
- Slave InPDO Map, OutPDO Map
- Master

ComilDE

Main tab

Config



From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:10_configurator&rev=1541985593

Last update: 2024/07/08 18:22