

Configurator	1
	1

Configurator

× Configurator

Configurator

- Slave
- Slave Topology Map
- Slave Address, SyncMode
- Slave InPDO Map, OutPDO Map
- Master



ComilDE

Main tab

Config



From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:10_configurator&rev=1564366954

Last update: **2024/07/08 18:22**