


Slave Info ..... 1  
..... 1  
..... 1  
Property ..... 2


# Slave Info

× Configurator Slave Information Tab  
Address, SyncMode, DeviceType




- SlaveInfo

- ESI Slave
- Address
- SyncMode



Property FMMU / SM



<b>Product</b>	ETS-A0402MV-E	<b>ProductCode</b>	0x5032D406
<b>Vendor</b>	COMIZOA	<b>VendorID</b>	0xAAAAAAAA
<b>Group</b>	ETS	<b>RevisionNo</b>	0x16102400

Address	
AddressMode <b>A</b>	<b>ALIAS</b>
Alias	580
AliasLMode <b>B</b>	<b>IdentificationADO</b>
AutoAddress	-6
PhysAddr_Hex <b>C</b>	<b>0244</b>
Info	
PhysicsType	YY
SyncMode <b>D</b>	<b>FreeRUN</b>
Support	
IsAoE	False
IsCoE	True
IsFoE	True
IsMbx	True
Type	
DeviceType_401 <b>E</b>	<b>A1, A0</b>
ProfileNo	401
SubProfileNo	12

Apply All **3**

### 1 - Info

- Slave Type

### 2 - Property

- Slave
- (default) ESI
- 가

### 3 - Apply All

- , Type Slave
- VendorID ProductCode가 Type

## Property

### AddressMode

- ALIAS : Master가 Slave Address
  - Slave
  - 가 OP Mode 가
- CSA : ALIAS Slave

### AliasILMode

- IdentificationADO : Slave ESC Memory
- IdentificationReg134 : Slave
  - MicroController ID Switch가

### PhysAddr\_Hex

- 16 Address
- 402 Profile(Driver) IO **BaseAddress**

× Address가 Download Slave

### SyncMode

- xml xml mode
- xml 가 , , FreeRUN
- 

From: <http://comizoa.co.kr/info/> - -

Permanent link: [http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:20\\_desc:30\\_slaveinfo&rev=1586446094](http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:30_slaveinfo&rev=1586446094)

Last update: 2024/07/08 18:22