

DC Delay	1
	1
DC Delay	1

DC Delay

× DC Mode

Delay Time




- **Config** Tab **DC.Delay**


- **DC Sync**

Slave

DC Delay




- TopologyView Table Delay가 ns .



- 'c:\windows' 'C:\Users\Win7\AppData\Roaming\COMIZOA'
- 'ComiEcatDCSetup.ini' .

```
[NET1_DC_DELAY]
NumSlaves=20
slave000=767, 0, 735, 0, 0, 0
slave001=768, 735, 720, 135, 0, 735
slave002=580, 720, 699, 0, 0, 1455
slave003=579, 699, 740, 0, 0, 2154
slave004=578, 740, 719, 0, 0, 2894
slave005=577, 719, 740, 0, 0, 3613
slave006=581, 740, 720, 0, 0, 4353
slave007=582, 720, 719, 0, 0, 5073
slave008=583, 719, 720, 0, 0, 5792
slave009=584, 720, 720, 0, 0, 6512
slave010=586, 720, 720, 0, 0, 7232
slave011=585, 720, 720, 0, 0, 7952
slave012=588, 720, 740, 0, 0, 8672
slave013=587, 740, 0, 0, 0, 9412
slave014=769, 135, 0, 0, 669, 18324
slave015=2, 669, 640, 0, 0, 18993
slave016=1, 640, 680, 0, 0, 19633
```

- Slave , Port Receive Time .
- Slave Disconnect Topology가
 - Slave delay가 .
 - Delay .



• Port ReceiveTime **Slaves** 가 .

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:60_dcdelay&rev=1586773655

Last update: 2024/07/08 18:22