

Module Change	1
Info	1

Module Change

× Slave가 , Config Slave

The screenshot shows the 'M.Change' configuration window. At the top, there are tabs for 'Setup', 'Main', 'Address', and 'Config'. The 'Config' tab is selected. Below the tabs, there are icons for 'DC.Delay', 'MisConnect', 'M.Change' (highlighted with a red box), and 'Reset'. The main area contains a table with columns: Index, Alias, Address, and Name.

	Index	Alias	Address	Name
☐	2	0x7	0x0	[0007h] R88D-KN01H-ECT
☐	3	0x2	0x0	[0002h] R88D-KN01H-ECT
☒	10	0x246	0x0	[0246h] ETS-D08MN
☒	11	0x245	0x0	[0245h] ETS-D08MN

At the bottom, there are three buttons: 'Update', 'OK' (highlighted with a red box), and 'Cancel'.

- Slave가 , List
- **OK** (Checked)

X

Info

- EtherCAT Master , Slave Master가
- , 0x0 .
- Module Change .

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:80_module_change&rev=1587032622

Last update: **2024/07/08 18:22**