

**Config** ..... 1

# Config

## Configurator Configuration

### Config

- **Configurator**
- **Configuration**

### Description

- **Project**
  - Slave List
- **Setup : Configuration Option**
- **TopologyView**
  - Topology, AIStatus, AIStatus Error ,
  - Port , **InPort - OutPort** , DC Delay
- **Net Info**
  - Cycle Time, Process Time, Logic Memory
  - DI, DO, AI, AO Channel Map
- **Slave Info**
  - Address, SyncMode, DeviceType
- **Process Data**
- **Slot Info**
- **Addressing**
  - IO Module Channel Mapping
  - Auto Addressing
- **Distibuted Clock Delay**
- **Reverse Connected Slave**
- **Module Change**

### Trouble Shooting

- **Scan Error**

- **Master Device**
- 
- **Master-DC**
- **OP**

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

[http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1\\_setup:10\\_config:start](http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:start)

Last update: **2024/07/08 18:23**