


EtherCAT State Machine 1
 State Machine 1
 AI Status 1

EtherCAT State Machine

× EtherCAT State Machine AL Status



- Bootstrap :
 - FoE¹⁾ MailBox 가 .
 - Init ²⁾
- Init :
 - 가 .
- Pre-OP : MailBox 가
 - .
- Safe-OP : MailBox , TX PDO 가
 - Slave Status Data .
- OP : MailBox , TX PDO, RX PDO 가
 - 가 .
 - 가 가 .

AL Status

- Slave (State Machine) Master
 - Master ESC AL Control Register .
 - Slave ESC AL Status Register .

- Slave AL Status
 - AL Status ErrorCode
- Slave AL Status가 OP가 , 가
 - TX Slave(DI, AI) , SafeOP data
 - 가

1)

File access over EtherCAT

2)

Init → Bootstrap or BootStrap → Init

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=platform:ethercat:2_info:10_alstatus

Last update: **2024/07/08 18:23**