


State Machine	1
AI Status	1

EtherCAT State Machine


x EtherCAT State Machine AL Status



- BootStrap :
 - FoE¹⁾ MailBox 가 .
 - Init ²⁾
- Init :
 - 가 .
- Pre-OP : MailBox 가
 - .
- Safe-OP : MailBox , TX PDO 가
 - Slave Status Data .
- OP : MailBox , TX PDO, RX PDO 가
 - 가 .
 - 가 가 .

AI Status

- Slave (State Machine) Master
 - Master ESC AL Control Register .



1)
File access over EtherCAT

2)
Init → Bootstrap or BootStrap → Init

From:
<http://comizoa.co.kr/info/> - -

Permanent link:
http://comizoa.co.kr/info/doku.php?id=platform:ethercat:2_info:10_alstatus&rev=1586256984

Last update: **2024/07/08 18:22**