

Summary

```
namespace ...
{
    public class ...
    {
        public void Init()
        {
            // Master Device
            InitMasterDevice();

            // Config Scan . ( )
            CheckChannel();

            // 가
            AxisServoOn();

            //
            AxisHomeReturn();
        }

        private void InitMasterDevice()
        {
            //
            DeviceLoad();

            // 가
            CompareSlaveCount();
            // SW Version(FW, WDM, SDK)
            GetVersionCompResult();
            // Input / Output
            CheckReveseConnection();
            // Network alStatus OP
            SetAlStateToOP();
        }

        private void DeviceLoad() {}
        private void CompareSlaveCount() {}
        private void GetVersionCompResult() {}
        private void CheckReveseConnection() {}
        private void SetAlStateToOP() {}
        private void CheckChannel() {}
        private void AxisServoOn() {}
        private void AxisHomeReturn() {}
    }
}
```

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=platform:ethercat:70_users_guide:00_cookbook:20_systeminit:10_summary

Last update: **2024/07/08 18:23**