Home Mode

× EtherCAT Master   HomeMode   .

Driver HomeMode

- EtherCAT   37   HomeMode   .
- Driver   1 ~ 37   HomeMode   .
  - ○   HomeMode   .
  - ○   HomeMode   .
  - ○ Driver   HomeMode   Driver   .
- Driver HomeMode   , **Master   Drvier**   ,
                    .

Master HomeMode

- COMIZOA   EtherCAT Master   100 ~ 130   HomoMode   .
-                  HomeModeInfo   .
- Master HomeMode   CSP   Master   .
  - ○ Driver HomeMode   2cycle   .

From:
http://comizoa.co.kr/info/ - **-**

Permanent link:
http://comizoa.co.kr/info/doku.php?id=platform:ethercat:70_users_guide:10_homing:10_homemode

Last update: **2024/07/08 18:23**