

.....	1
Case 1 .....	1

× Torque가 0


### Case 1

- InPDO Data Torque

- 1)

- InPDO Data Torque 가 Configuration PDO Map

  - Torque



- Config Configuration Guide

1)  
InPDO Data

From:  
<http://comizoa.co.kr/info/> - -

Permanent link:  
[http://comizoa.co.kr/info/doku.php?id=platform:ethercat:70\\_users\\_guide:20\\_ts:torque\\_monitor\\_failed](http://comizoa.co.kr/info/doku.php?id=platform:ethercat:70_users_guide:20_ts:torque_monitor_failed)

Last update: **2024/07/08 18:23**