



DLL_Logger

× DLL_Logger

-


1 Comiide.exe



-

Motion view

DLL



- Start DLL_Logger .
- **Start** Logging .
- Memory **Dump** File Log 가 Viewer file
- LogType LogView , , **Stop** Log 가

The screenshot displays the DLL_Logger application interface. On the left, a log window shows a series of commands and responses for Axis0, such as 'cmmSxSetSpeedRatio' and 'cmmSxVMoveStart'. The right side of the interface is the SxMotion control panel, which includes a position monitor with 'Command Position' and 'Feedback Position' fields, jog mode settings (Velocity Move, Relative Position Move, Absolute Position Move), and speed settings (Speed Ratio % set to 100%).

DLL_Logger

DLL_Logger

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=practice:dll_logger_%EC%82%AC%EC%9A%A9%EB%B2%95&rev=1625641528

Last update: **2024/07/08 18:23**