

Topology View

.....

.....

Main View

AI Status Control Panel

Display Control Panel

1

1

1


2

4


4

Topology View

× Configurator Topology View



- Topology




- 1. MainView : Table Line Topology
 - Slave
 - Slave ESC Memory Read / Write / Update
- 2. **AI Status** Control Panel
 - Slave AI Statue
- 3. Display Control Panel
 - MainView

Main View

- Table ESC
- Table 가
 - Physical Address (Hexa)
 - SlaveType (Servo / DI / DO)
 - DC Delay
 - Port ,
 - AI Status




- Physical Address : **0x0003**
- SlaveType : **Servo**
- DC Delay : **2075ns**
- Port : 2 가 Port 1 port(Inport) (Open)
- AIStatus : **OP**
- ESC가 , E-BUS




Table


가



- Get AIStatus Error
 - AI Status가 , Error Code



- Memory Read / Write
 - EEPROM, Coe SDO, Register Read / Write
 - **SlaveR/W**
- EEPROM Update
 - EEPROM ConfigData Update
 - **SlaveR/W**



× **Warning!**
EEPROM_READ_FAILED ScanError 가 , Slave
Topology가 .

AI Status Control Panel

- Slave AI Status .
- Disconnect AI Status가
 ◦ Disconnect .
- AI Status 가 , Get AIStatus Error Error
 .
- AI Status ErrorCode 가 0 , **AI Status** .

Display Control Panel

- **Update** : MainView .

- + : MainView .
- - : MainView .

From:

<http://comizoa.co.kr/info/> - -

Permanent link:

http://comizoa.co.kr/info/doku.php?id=platform:ethercat:1_setup:10_config:20_desc:10_topologyview&rev=1587002643

Last update: **2024/07/08 18:22**